AiXPI 10" LED Ring Light

Instructions



Dear Customer:

Thank you for purchasing our products. If you need any help, please feel free to contact us at our customer service email:

support@aixpi.com

The ring light from AIXPI were addressed 30-day full money refund policy and 12-month quality guarantee.






The phone scans the QR code to watch the installation video.


Precautions for use

- No battery, No charging.
- Please chose reputable brand, certificate compliant DC 5V adapter. It is better to choose a 12w or larger adaptor to power the ring light. If the adaptor power is smaller than 12w, it may happens over heating protection to cut off the ring light automatically.
- 2.The slight noise is unavoidable, if you chose power bank to drive the ring light.
- 3. Ta: -20°C ~ 50 °C
- 4. IP20, Never use it in damp environment, such as in the rain,in the bathroom etc.






3 Color Temperature & 10 Brightness



Product List



Installation Instructions



1.Prepare **@Pan-Tilt** and **⑤Mobile clip**.



2.Install the Mobile clip on the Pan-Tilt tighten it as shown in the direction of the arrow.




3.Loosen the bottom screw and have a certain gap for easy installation on the ring light.



4.Mount the assembled mobile phone holder on the ring of the ring light.



5.As shown in the figure, press the clamp with your finger and rotate until tightened.



6.Install the pan-lik on the ring lamp and rotate until tightened.



7.Install the Tripod on the Pan-Tilt and rotate until tightened.



8.Clamp the cell phone on the cell Mobile clip.



9.Complete assembly.